



TECHNIWATCH

swiss precision tools

ROTARY BEZEL EXTRACTING PLIERS

Versatile and efficient

VERY EASY TO USE, THIS PLIERS/VICE ASSEMBLY CAN REMOVE MOST ROTARY BEZELS ON THE MARKET.

The multi-function vice was designed to ensure safe operation, providing a large handle. Its two jaws, made from synthetic material, enable you to hold watch heads via their horns, without scratching them.

The pliers are equipped with a versatile elastomer for all bezel diameters ranging from 30 to 50 mm, to provide a superior grip. There is a limit stop to prevent crushing the bezel after extraction. This solution is without doubt the most efficient on the market.



Technical specifications:

- Elastomer with two lips, suitable for rotary bezels of $\varnothing 30$ to 50 mm
- 4 possible shapes on the vice jaws

Size:

105 x 205 x 19 mm (pliers)
60 x 70 x 102 mm (vice)

Weight:

270 grammes (pliers)
255 grammes (vice)

References:

E305300 (pliers)
E305400 (vice)

Techniwatch SA

Route de la Jaluse 5b,
2400 Le Locle
Tel : 032 926 19 46
www.techniwatch.ch

Discover our presentation videos on our YouTube channel « Techniwatch SA »
Also accessible by scanning the following QR code





TECHNIWATCH

swiss precision tools

PINCE EXTRACTEUR DE LUNETTE TOURNANTE

Détails du produit



PRÉCONISATIONS :

Pour une montre bracelet, il est possible de se passer de cet étau mais l'opération sera moins facile.

Dans le cas où vous avez démonté le bracelet, positionner la carrure sur l'étau en ayant préalablement choisi la forme du mors adaptée aux cornes.

Serrez fortement l'étau

De l'autre main, prenez la pince et glissez la lèvre entre la lunette et la carrure. Choisir le côté de la pince en fonction du diamètre de lunette.

Serrez légèrement la pince et tourner là de façon à mettre en rotation la lunette sur $\frac{1}{4}$ de tour environ. Pendant cette opération, il est important d'exercer une torsion radiale avec l'étau.

REPLACEMENT ELASTOMERE ET MORS :

L'élastomère se remplace à l'aide d'une clé 6 pans de 1.5 mm

Les mors peuvent être tournés et vissés à l'aide d'un tournevis plat de mécanicien.



Techniwatch SA

Route de la Jaluse 5b,
2400 Le Locle
Tel : 032 926 19 46
www.techniwatch.ch

Discover our presentation videos on our YouTube channel « Techniwatch SA »
Also accessible by scanning the following QR code





TECHNIWATCH

swiss precision tools

PINCE EXTRACTEUR DE LUNETTE TOURNANTE

Accessoires

	Produits	Références
	Elastomère de remplacement	E305201
	Jeu de mors de remplacement	E305309

